

# Recessed Hose Box Installation Instructions - Model 7904

**Steps** (Refer to the figures below when installing hose box.)

1. Select the location on the wall where the recessed hose box is to be installed.
2. Scribe horizontal and vertical centerlines on the wall.
3. Rough-in a 10" (254mm) high x 8" (203mm) wide opening in the wall for the hose box.
4. *For 3/4" Wall Thickness:* Place the hose box in the wall opening. Secure the hose box using the four tabs on the side of the box and wall fasteners (supplied by installer).

*For Walls Greater Than 3/4" Thick:* Remove the four tabs from the hose box using the hex key provided. Place the hose box in the wall opening and anchor the hose box to the wall through the holes in the side of the box (fasteners supplied by installer).

5. Connect supply piping to the 1/2" nom. copper tube inlets (piping supplied by installer).
6. Complete piping connection to 3/4" male hose fitting (piping supplied by installer).

