

- 1. Remove Coin Box Lock Plate from the Coin Box.
- 2. Attach the Coin Box to the S100 Lock Mechanism (engage the two tabs on the lower back edge of the Lock with the upper horizontal slot on the Coin Box).
- 3. From the back side of the door align and insert the Lock Cylinder into the $\frac{7}{8}$ " diameter hole located in the door.
- 4. Use the mounting screws (FAST-LF035, FAST-LF039, FAST-LF005) supplied with the Lock and fasten the lock to the inside of the door as shown.
- 5. Reattach the Coin Box Lock Plate to the Coin Box.