

# Penal Filler-Bubbler or Filler Only Installation Instructions

Steps (Refer to the figures below when installing penal filler.)

1. Position the penal filler over the prepunched square hole in the cabinet. **NOTE:** For filler-only applications, rotate the filler 180° from what is shown below.
2. Secure the penal filler to the cabinet using the two screws provided.
3. Tighten the screws. **NOTE:** The method of supply connection to the back of the penal filler is dependent on the operating valve installed. Refer to the valve installation instructions to make the supply connection to the penal filler.

